

SI-9300R Battery Analyzer

The Solartron Analytical SI-9300R is a modular, multichannel battery analyzer that offers unrivaled measurement and diagnostic capabilities for the analysis of battery cell technologies intended for energy and power applications.

More Than a Cycler

Industry demand for better batteries with higher capacity, shorter charge time and longer life represents a significant measurement challenge. Solartron Analytical has developed a suite of battery measurement and analysis tools intended for high power cells based on direct insights from the market and understanding of customer workflows.

Each module consists of five independent analyzer channels, each capable of 3 kW power. Up to eight modules can be installed in a 42U rack (40 channels) or four modules in 24U rack option (20 channels).

Key Measurement Specifications

- Regenerative technology to reduce power and increase channel packing density
- Flux Gate Current Sensor Technology for high accuracy and excellent temperature stability
- Current Accuracy of 0.03% FSR, 300 A, 20 A and 2 A current Ranges
- 10 kHz Solartron Analytical EIS on board on every channel as standard with real-time EIS fitting for instant cell diagnostics
- Up to 10 V polarization suitable for single cells and small eV modules
- Two auxiliary voltage measurement channels on every channel for DC and EIS anode/cathode characterization
- Patent pending Direct to Disk technology for increased system reliability and reduced PC high channel count data overload
- Ability to parallel channels of module for 1000 Amp measurements
- Patent pending EIS SoH algorithm for NISSAN LEAF and other pouch cell formulations for rapid cell grading applications



Save Energy, Optimize Power



Regenerative Technology



Multiple current ranges, 300 Amp · 20 Amp · 2 Amp



Impedance measurement as standard



Real-time data analysis



Regenerative Technology

End users are conscious of cost of ownership and cost of test. The SI-9300R utilizes regenerative technology that reduces operating costs.



REDUCING COST OF TEST

Energy recovery algorithms in software either return current to the grid or actively balance energy within a module to achieve energy savings of up to 90% versus non return to grid technology representing significant energy and cost savings.

CONSERVING SPACE

Since energy is recycled, little space is required for cooling of electronic components. This allows the SI-9300R to achieve a high channel count density in a single 19" cabinet – up to three times the number of channels compared with non-regenerative systems. When test space constraints represent a challenge, the SI-9300R maximizes test capabilities while optimizing lab space.

AMETEK =	1	Running	-	2 Overload		• 3) Claimed	=	4^{Idle}		=	5 ^{Main}	tenance	
60 RPM 🕈 RACK ID	STEP Rest	TYPE	S 00:22:19	STEP TYPE ConstantLevel	\$ 00.05	36 ST Rei	EP TYPE st	S 00:10:10	STEP TYPE Rest	S 00:	22:19	STEP TYP Impedance		00.45.0
inv_2A MODULE ID														
40D17452		CYCLE		Сүс	ile 🔪		CYCLE			CYCLE			CYCLE	
NET POWER 39 W POWER TO GRID 105 W		97/20 01:19:27	0	128 / 01:1			59/20 01:45:08			7/200 01:19:27)	1	0/200 00:54:37	
NTERNAL HEAT		T 03:45:2	27	T 03:4	45:27		T 05:45:	30	т	03:45:27		т	06:21:2	э
:14 W	2	CHARGING	47%	CHAR	SING 7	5% 🔒	DISCHARGIN	G 50%	a Di	SCHARGING	10%	1 DI	ISCHARGING	95
olartron	¢	8.31 V 102.15 mA 13.12 mAh		8.3 4119.4 14.2	mA	<i>,</i> ,	8.25 V 115.2 mA 15.08 mAh	,	٠	8.25 V 115.2 mA 15.08 mAh	,	۰.	8.25 V 115.2 mA 15.08 mAh	,



Multi-range, Flux Gate Sensor Technology

The system utilizes a three-current range, flux gate sensor. It is ideally suited for both high C Rate tests and trickle charge measurements with no loss in accuracy nor precision. Flux gate sensor technology offers up to five times better temperature stability than shunt technology. As a result, accuracy is not compromised by temperature changes in the measurement circuitry.

Temperature Measurement

Our PoE (power over ethernet), temperature measurement unit offers time-stamped temperature or voltage measurement. Up to 16 measurements per analyzer channel are possible. Operators no longer need to manually correlate temperature measurements with other data sets.

Direct to Disk Technology


The SI-9300R Battery Analyzer uses revolutionary Direct to Disk technology for data storage (patent pending). In this system, the cyclers themselves directly store data to central network drives without assistance from the PC. This increases system reliability, vastly reduces PC data loading, reduces network traffic, and ensures data are transferred with minimal delay. As the PC is not responsible for storing data, should there be a power outage, there is zero effect on test completion. This releases the PCs to perform core functions for which they are well designed, such as: organizing which tests to run, system monitoring and data analysis. The additional benefit is that PCs can easily be added, relocated, removed from the network without affecting test execution.

Affordable, EIS as Standard

Solartron has incorporated its renowned FRA technology on each measurement channel. Unlike expensive multiplexed solutions, Solartron has been able to deliver this capability without increasing the cost of the system. Furthermore, each channel has two auxiliary voltage measurement channels as standard allowing impedance measurements on individual anode and cathode within a cell. The SI-9300R offers all of this plus the ability to live fit EIS data while tests are in progress for instant cell diagnostics.

SI-9300R Impedance Accuracy

EIS accuracy is a key feature of this system:



EIS CONTOUR MAP The system has been optimized for EIS measurements of pouch and prismatic cells.

NISSAN LEAF SoH Algorithm In collaboration with the Warwick Manufacturing Group (WMG, UK), Solartron Analytical has developed a State of Health Algorithm specifically for NISSAN LEAF modules. Unlike time consuming pulse power tests, our patented algorithm can provide the SoH of a cell in less than three minutes with an accuracy of +/- 3%. This provides significant cost and time benefits for grading cells for second life applications.





Measurement Configuration

4 terminal						
·						
300 Amp (60 s pulse), 200 Amp continuous						
300 Amp, 20 Amp, 2 Amp						
0.03% FSR						
+300 mV to +10 V						
≤ ±0.01% Setting						
≤ 40 μV						
0.02% FSR						
0.03% FSR						
200 Amp step in < 1 ms						
10 mHz to 10 kHz						
1 mHz						
10 Amp RMS						
16 channels per measurement unit						
К, Ј						
2 per main measurement channel (enables DC V and EIS measurement)						
Same specifications as main voltage measurement channel						
1 per module						
1 per module, TTL protocol						
8 modules [4U size] per cabinet, 40 channels, 2050H x 1000D x 620W (mm)						
4 modules [4U size] per cabinet, 20 channels, 1255H x 1000D x 620W (mm)						
3 phase, 200 Vac to 480 Vac, Return to Grid						

Specifications subject to change.



